

Installation, Operation & Maintenance Manual End Suction Centrifugal Pumps



IMPORTANT! - Read all instructions in this manual before operating or servicing a pump.

North America: 866 777 6060 Int'l: +1 267 404 2910 Springer Pumps Springer Parts Last update: 12/06/2022 www.springerpumps.com www.springerparts.com Before installation, read the following instructions carefully. Failure to follow instruction and safetv information could cause serious bodily injury, death and/or property damage. Each Barmesa product is carefully inspected to insure proper performance. Closely following these instructions will eliminate potential operating problems, assuring years of trouble-free service.

▲ DANGER Indicates an imminently hazardous situation which, if not avoided, WILL result in death or serious injury.

▲ WARNING Indicates an imminenty hazardous situation which, if not avoided, MAY result in death or serious injury.

▲ CAUTION Indicates a potentially hazardous situation which, if not avoided, MAY result in minor or moderate injury.

IMPORTANT! - Barmesa Pumps is not responsible for losses, injury or death resulting from failure to observe these safety precautions, misuse, abuse or misapplication of pumps or equipment.

ALL RETURNED **PRODUCTS MUST BE** CLEANED, SANITIZED, OR **DECONTAMINATED PRIOR TO** SHIPMENT, TO INSURE EMPLOYEES WILL NOT BE **EXPOSED TO HEALTH HAZARDS IN** HANDLING SAID MATERIAL. ALL APPLICABLE LAWS AND

A WARNING Installation, wiring, and iunction connections must be in accordance with the National Electric Code and all applicable state and local codes. Requirements may vary depending on usage and location.

WARNING Installation and servicing is to be conducted by qualified personnel only.

Keep clear of suction and discharge openings. Do not insert fingers in pump with power connected; the impeller can cause serious injury.



Always wear eye protection when working on pumps. Do not wear loose clothing that

may become entangled in moving parts.



▲ DANGER Pumps build up heat and pressure during operation. Allow time for pumps to cool

before handling or servicing the pump or any accessory items associated with or near the pump. Do not block or restrict the discharge pipe/hose.

A WARNING Do not pump hazardous materials (flammable, caustic, etc.) or use these pumps in water over 160 °F. Do not exceed manufacturers recommended maximum performance, as this could cause the motor to overheat.



△ DANGER This pump is not intended for use in swimming pools or water installations where there is

human contact with pumped fluid.



△ DANGER Risk of electric shock. To reduce risk of electric shock, always disconnect pump from power source before

handling any aspect of the pumping system. Lock out power and tag.

▲ DANGER Do not lift, carry or hang pump by the electrical cables. Damage to the electrical cables can cause shock, burns or death. Never handle connected power cords with wet hands. Use appropriate lifting device.

△ **DANGER** Failure to permanently ground the pump, motor and controls before connecting to power can cause shock, burns or death.

△ WARNING Carefully read instruction manuals supplied with motor or engine before operating or servicing.

IMPORTANT! - Prior to installation. record Model Number, Serial, Amps, Voltage, Phase and HP from pump name plate for the future reference. Also record the Voltage and Current Readings at Startup:

1 Phase	Models				
Amps:	Volts:				
3 Phase	Models				
Amps L1-2:	Volts L1-2:				
Amps L2-3:	Volts L2-3:				
Amps L3-1:	Volts L3-1:				
Model Number:					
Serial:					
Phase: HP:					

Springer Pumps Springer Parts

SUCTION: DISCHARGE: LIQUID TEMPERATURE: VOLUTE: INTERMEDIATE COUPLING: IMPELLER: SEAL: SHAFT SLEEVE: O-RINGS: MOTOR: PAINT:	2" - 3" NPT. 1½" - 2½" NPT. 160°F (71°C) max. Cast iron ASTM A-48 class 30. Cast iron ASTM A-48 class 30. Closed, dynamically balanced. Stainless steel 304. Mechanical, type 01. Ceramic stationary part, carbon ring seal and exclusion in the rotating part. Buna-N elastomer and stainless steel spring. Stainless steel. Buna-N. High quality premium efficiency TEFC electric motors, designed & developed inaccordance with industry standards for industrial and commercial pumping applications. Air dry enamel, water based.
K 4 HOLES	F C DISCHARGE
MODEL PART No. SIZE H IB1½-3-2-1 62071061 3 <t< th=""><th>1 3500 182JM 1 3500 182JM 5 1 3500 184JM 5 1 3500 - 3 1750 - 5 3 3500 143JM 5 3 5000 143JM 6 3 3500 143JM 7 7.38 4.58 4.58 7 10 5.5 4 2.09 6.13 3.55 7.31 0.34 6 3 3500 145JM -</th></t<>	1 3500 182JM 1 3500 182JM 5 1 3500 184JM 5 1 3500 - 3 1750 - 5 3 3500 143JM 5 3 5000 143JM 6 3 3500 143JM 7 7.38 4.58 4.58 7 10 5.5 4 2.09 6.13 3.55 7.31 0.34 6 3 3500 145JM -
IB2-5-2-1 62071072 9 IB2-7.5-2-1 62071073 7 IB2-1-4 62071021 1 IB2-1.5-4 62071022 1 IB2-2-2 62071023 X IB2-2-4 62071024 X	1 3500 182JM 1 3500 184JM 5 1 3500 184JM 5 1 3500 - 3 1750 - 5 3 1750 - 5 3 1750 - 4 3 3500 143JM 7.13 10 5.5 5.5 3.5 7.5 4.5 9.28 0.41 7.13 10 5.5 5.5 3.5 7.5 4.5 9.28 0.41 7.13 10 5.5 5 2.09 6.13 3.55 7.31 0.34 7.13 10 5.5 4.2 2.09 6.13 3.55 7.31 0.34 7.13 10.5 5.5 4.5 9.28 0.41 - <t< th=""></t<>
IB2½-7.5-2-1 62071082 7 IB2½-1-4 62071041 1 IB2½-1.5-4 62071042 1 IB2½-2-4 62071043 5 IB2½-3-4 62071044 5 IB2½-5-2 62071045 5 IB2½-5-2 62071045 5 IB2½-5-2 62071046 7 IB2½-10-2 62071047 1 IB2½-15-2 62071048 1	5 1 3500 - 3 1750 - 5 3 1750 - 5 3 1750 - 2 3 1750 - 4 3 1750 - 5 3 1750 - 6 3 1750 - 6 3 1750 - 6 3 1750 - 7 3 10 5.5 5 2.09 6.13 3.5 7.31 0.34 6 3 3500 184JM 5 3 3500 213JM -

All dimensions are in inches, and may vary depending on the motor manufacturer.

North America: 866 777 6060 Int'l: +1 267 404 2910

Springer Pumps Springer Parts

Receiving inspection

Upon receiving the pump, it should be inspected for damage or shortages. If damage has occurred, file a claim immediately with the company that delivered the pump. If the manual is removed from the packaging, do not lose or misplace.

▶ Storage

Any product that is stored for a period longer than six (6) months from the date of purchase should be bench tested prior to installation. A bench test consists of, checking the impeller to assure it is free turning and a run test to assure the motor (and switch if provided) operate properly.

At any time exceeding six (6) months, but no more than twenty four (24), the equipment must be stored in a controlled area, keeping it away from contact with rain, dust, etc., and the temperature is maintained between 43-104 °F. If there is a possibility of high humidity (coastlines, etc.), the entire unit must be sprayed with antioxidant liquid.

Service Stations

To find the nearest Barmesa Pumps authorized service shop, please directly contact your distributor or the factory.

Installation

The pump should be as close as possible to the liquid to be pumped, with a minimum number of couplings, adapters, etc., in order to reduce friction on the suction side.

The suction and discharge piping must be perfectly aligned in the pump volute and supported independently using support or anchors, this to prevent excessive load on the volute.

The anchors of the motor are to be anchor, on a raised base, approximately 4", this to prevent accumulated water from entering the motor.

**See friction table in pipes and fittings to determine the dimensions of the suction and discharge. (Page 8)

Suction

Use pipe or hose reinforced sufficiently robust to prevent collapsing by the difference in atmospheric pressure. Check for leaks at all joints.

A successful operation depends on the calculation of the friction loss in the suction, considering acceptable limits. The minimum suction pipe size to use can be determined by comparing the NPSH available at the pump suction against the NPSH required by the impeller, as shown in the performance curves.

Usually, we recommend using a pipe diameter of 1/2" to 1" greater as that of the suction volute or body.

A strainer or sieve should be installed in the suction to prevent the entry of objects. The strainer must have a free entry area at least three times the pipe diameter. Usually a suction valve is combined with a strainer *Figure 1*.



North America: 866 777 6060 Int'l: +1 267 404 2910 Springer Pumps Springer Parts



North America: 866 777 6060 Int'l: +1 267 404 2910

Springer Pumps Springer Parts





In order to determine the optimal size of the piping, compare the total cost of the equipment's operation of (cost the pump, control equipment, piping and energy consumption). By increasing the discharge diameter reasonably, it reduces the required BHP due to the low friction. Perform different tests using several piping diameters until you find the more convenient.

The pipe, valves, etc. should be perfectly align with the volutes suction and discharge centerlines, this to avoid any excessive loads on the pumps volute. If needed, install new expansive joints to protect the pump from excessive thermal or pressure forces.

Pre-Operation

1. Check Voltage and Phase -Compare the voltage and phase information stamped on the pump name plate.

2. Check Pump Rotation - Improper motor rotation can result in poor pump performance and can damage the motor and/or pump. Check rotation on three phase units by momentarily applying power and observe the "kickback".



Kickback should always be in a counter-clockwise direction ลร viewed from motor end or opposite to impeller rotation. Impeller rotation is counter-clockwise as viewed from bottom of pump.

3. Name Plate -Record the information from the pump name plate to drawing in front of manual for future reference.

4. Priming - Every centrifugal pump must be primed (suction pipe and pump's body should have liquid), before operating.

Install the foot valve at the suction pipe Figure 1 and fill with liquid the superior part of the pump's body. Sometimes air is trapped inside the body, to remove it you should uncap the male plug until the liquids spills out. Re-install the male plug using a sealant.

-

Do not

without



Springer Pumps Springer Parts

▶ Starting

When starting for the first time your equipment check that the discharge valve is 90% closed. Gradually open the valve until the motor runs at full load (amperage plate). Never allow the amperage consumed by the pump exceeds the maximum permitted by the engine.

Mechanical seal

Mechanical seals installed in this pumps are lubricated by water, there for the pump should not be operated dry. You will find the appropriate seal for each use and liquid to be pumped, check with your Barmesa Pumps distributor for more information.

> IMPORTANT! - Always unplug the pump before applying maintenance, service or repair to avoid electric shock.

► Maintenance

Body and Impeller - All pump parts are removable by removing nuts and bolts. For body maintenance, disconnect the suction and discharge, and remove the body of the intermediate coupling. For maintenance of the impeller is not necessary to remove the suction or discharge, simply remove the body nuts; this would uncover the impeller. Examine and replace if it shows wear or damage.

When the impeller requires replacement, remove the screw of the shaft, and using a puller, remove the impeller being careful not to abuse the keyway of the shaft.

It is important not to overfill the oil tank because it would cause an increase in pressure by heating, affecting the bearings and seals. In normal operation, the frame temperature increases 122 °F above ambient temperature.

Mechanical Seal - To inspect or replace the shaft seal, remove the body and impeller. If any part shows wear or damage, replace both parts (stationary seat and rotary part). The rotating seal parts may be stuck together with the shaft, this happens when the seal has been assembled for a long time.

If the mechanical seal does not leak and there is need to open the pump for inspection or cleaning, *DO NOT* remove the seal, remove the spring only if the impeller needs to be removed. Once a seal has been in operation is very difficult to remove and reassembly without creating a seal leak.

Disassembly

Mechanical Seal - Perform the steps above. Remove the rotating part. It may be necessary to remove the intermediate link to remove the stationary seat. To do this, remove the nuts and washers that attach the coupling to the motor. When removing the coupling, the steady part will move towards the front seat of the shaft and the sleeve. If the seat does not yield itself, push from the rear of the coupling.



Handle seal parts with extreme care. DO NOT damage lapped surfaces.

Reassembly

Mechanical Seal - Identify all parts of *Figures 7* and *8*. The ring (6) and seat (1) are perfectly polished, so care must be taken not to scratch or smudge. The cleaning during the assembly process is very important.



IMPORTANT! - All parts must be clean before reassembly. Step 1: Install the intermediate coupling if it was previously removed. Make sure the shaft and cavities, where will it seats, are clean. The shaft sleeve should not be sharp, but a radius of about 1/32". It is recommended that lightly polish the area of the shaft. If the shaft and it radius are perfectly polished, the seal can be relatively easily installed.

Step 2: Install the seat assembly (1 and 2) on the inside of the intermediate coupling, slightly moistening with water on the rubber parts (**do not use grease or oil**). This assembly should be done only manually, meaning without the use of an instrument.

Step 3: Install the rotating portion of the seal without the spring. Moisten the arrow and the inside of the seal with some water (**do not use grease or oil**). With clean, dry hands, insert the rotating portion to the shaft, sliding it abuts the stationary seat. Once the seal is in place, insert the spring (5).

Step 4: Place the impeller and washers; tighten the hex screw.

North America: 866 777 6060 Int'l: +1 267 404 2910 Springer Pumps Springer Parts



North America: 866 777 6060 Int'l: +1 267 404 2910 Springer Pumps Springer Parts

Table 1

1 Friction in meters x 100 m of piping.

LITERS					PIPIN	IG DIAN	IETER					GALLO
PER	1"	11⁄4"	11⁄2"	2"	2 ½"	3"	4"	5"	6"	8"	10"	PER
MINUTE		1 74	172	2	2 72	3	7		Ŭ	•		MINU
30	4.54											8
37	6.86	1.77										10
45	9.62	2.48										12
57	16.2	4	1.53									15
68	20.6	5.22	2.42									18
76	25.1	6.34	2.94									20
95	38.7	9.6	4.48	1.2	0.54							25
113	54.6	13.6	6.26	1.82	0.75							30
151	95	23.5	10.79	3.1	1.28							40
170	119	29.4	13.45	3.85	1.6							45
189	146	36	16.4	4.67	1.94	0.66						50
208		43.2	19.7	5.51	2.33	0.79						55
227		51	23.2	6.59	2.72	0.92						60
246		59.6	27.1	7.7	3.17	1.07						65
265		68.8	31.3	8.86	3.63	1.22						70
284		78.7	35.8	10.15	4.14	1.39						75
303		89.2	40.5	11.4	4.66	1.57						80
322		100	45.6	12.6	5.27	1.77						85
360		125	56.5	15.8	6.49	2.18	0.57					95
378		138	62.2	17.4	7.11	2.39	0.62					100
416			75.25	21.05	8.55	2.88	0.75					110
454			88.3	24.7	10	3.37	0.88					120
530			119	33.2	13.5	4.51	1.17	0.38		_		140
568			137.5	38.1	15.45	5.16	1.33	0.43				150
605			156	43	17.4	5.81	1.49	0.48				160
643				48.55	19.65	6.54	1.67	0.54				170
681		310		54.1	21.9	7.28	1.86	0.6				180
757		211	101	66.3	26.7	8.9	2.27	0.73	0.3			200
833	- 15	(\circ)		80	32.2	10.07	2.72	0.87	0.35			220
908				95	38.1	12.6	3.21	1.03	0.41			240
984	- (t			111	44.5	14.7	3.74	1.2	0.48			260
1060				128	51.3	16.9	4.3	1.38	0.56			280
1135				146	58.5	19.2	4.89	1.58	0.63			300
1324			T/ N	. 10	79.2	26.1	6.55	2.11	0.85			350
1514					103	33.9	8.47	2.72	1.09	0.27		400
1892					100	52.5	13	4.16	1.66	0.42		500
2082						63.2	15.7	4.94	2	0.12		550
2002						74.8	18.6	5.88	2.34	0.59	0.19	600
2649						101	25	7.93	3.13	0.79	0.15	700
2838				1000		101	28.7	9.07	3.59	0.91	0.29	750
3028				-			32.4	10.22	4.04	1.02	0.25	800
3217					7		36.6	11.56	4.5	1.13	0.32	850
3406							40.8	12.9	5.05	1.13	0.30	900
3595							45.5	14.35	5.61	1.42	0.41	900
3785							45.5 50.2	14.55	6.17	1.56	0.45	1000
4163							50.2	19.15	7.41	1.87	0.5	1100
4103								22.5	8.76	2.2	0.0	1200
4920								26.45	10.2	2.2	0.7	1300

NOTE: The values in this table refer to frictions and clean water pipes and hoses smooth walls. As used pipe and / or hose rough walls increase the values about 50% to 100%.

Springer Pumps Springer Parts

PART	DESCRIPTION				DI	AMET	ER			
PANI	DESCRIPTION	1"	1¼"	11⁄2"	2"	2 ½"	3"	4"	5"	6"
	STANDARD 90° ELBOW	0.84	1.07	1.22	1.68	1.98	2.44	3.35	4.12	4.88
	MEDIUM RADIUS ELBOW 90°	0.69	0.92	1.07	1.37	1.68	2.14	2.75	3.51	4.27
a	LONG RADIUS ELBOW 90°	0.54	0.69	0.84	1.07	1.37	1.6	2.14	2.75	3.36
8	STANDARD 45° ELBOW	0.38	0.54	0.61	0.77	0.92	1.15	1.53	1.83	2.29
	STANDARD TEE	1.68	2.29	2.75	3.36	4.28	5.19	6.71	8.23	10.1
	ANGLE GLOBE VALVE (OPEN)	3.97	5.49	6.71	8.23	10.7	12.2	16.8	21.3	25.9
	GLOBE VALVE (OPEN)	7.93	10.7	13	16.8	21.3	24.4	35.1	42.7	48.8
	GATE VALVE (OPEN)	0.19	0.25	0.29	0.38	0.43	0.54	0.69	0.84	1.07
	INCREASER	1.21	1.52	1.82	2.74	3.35	4.26	6.09	7.92	10.1
	REDUCER	0.3	0.3	0.3	0.61	0.61	0.9	1.21	1.21	2.13
	SUCTION VALVE	0.91	1.21	1.52	2.13	2.74	3.35	4.87	6.4	7.92

Table 1Equivalent length in meters of straight pipe and valve connections for calculating friction.

North America: 866 777 6060 Int'l: +1 267 404 2910 Springer Pumps Springer Parts



North America: 866 777 6060 Int'l: +1 267 404 2910

Springer Pumps Springer Parts

► Model IB2

ITEM	PART No.	DESCRIPTION	QTY.
1	03090051	Volute case	1
	03140101	Impeller Ø4.125" (2 HP, 3600 RPM)	
	03140101B	Impeller Ø4.750" (3 HP, 3600 RPM)	
2	03140101C	Impeller Ø5.375" (5 HP, 3600 RPM)	1
2	03140101D	Impeller Ø6.062" (7.5 HP, 3600 RPM)] '
	03140101E	Impeller Ø6.250" (10 HP, 3600 RPM)]
	03140101L	Impeller Ø6.250" (1.5 HP, 1750 RPM)]
	03010026	Bracket, "AK" Fit 4½" (1.5 to 7.5 HP)	- 1
3	03010027	Bracket, "AK" Fit 8½" (10 HP)] '
4	30400809	Shaft sleeve	1
5	92010029J	O-Ring shaft sleeve	1
6	31030131	Mechanical seal	1
7	92010014	Slinger	1
8	92010034	O-Ring	1
9	91010345C	Impeller's screw, 3/8"-16UNC x 1¼" SS	1
10	91010061	Lock washer 3/8" SS	1
11	30400418	Impeller washer	1
12	30400631	Shaft key	1
13	91010304	Stud 3/8"-16UNC x 1.63"	8
14	91010413	Hex nut 3/8"	8
15	91010012	Lock washer 3/8" steel	8
16	91010242	Cap screw (1.5 to 7.5 HP)	- 4
10	91010262	Cap screw (10 HP)	4
17	91010012	Lock washer (1.5 to 7.5 HP, not required for 10 HP)	4
18	93010143	Pipe plug 1/4" NPT	2

DS

Model IB21/2

ITEM	PART No.	DESCRIPTION	QTY.
1	03090052	Volute case	1
	03140102	Impeller Ø4.750" (5 HP, 3600 RPM)	
	03140102B	Impeller Ø5.125" (7.5 HP, 3600 RPM)	
2	03140102C	Impeller Ø5.500" (10 HP, 3600 RPM)	1
•	03140102D	Impeller Ø6.312" (15 HP, 3600 RPM)	
	001101020	Impeller Ø6.312" (2 HP, 1750 RPM)	
3	03010026	Bracket, "AK" Fit 4½" (2 to 7.5 HP)	1
	03010027	Bracket, "AK" Fit 8½" (10 to 15 HP)	Ľ
4	30400809	Shaft sleeve	1
5	92010029J	O-Ring shaft sleeve	1
6	31030131	Mechanical seal	1
7	92010014	Slinger	1
8	92010034	O-Ring	1
9	91010345C	Impeller's screw, 3/8"-16UNC x 1¼" SS	1
10	91010061	Lock washer 3/8" SS	1
11	30400418	Impeller washer	1
12	30400631	Shaft key	1
13	91010304	Stud 3/8"-16UNC x 1.63"	8
14	91010413	Hex nut 3/8"	8
15	91010012	Lock washer 3/8" steel	8
16	91010242	Cap screw (2 to 7.5 HP)	4
10	91010262	Cap screw (10 to 15 HP)	-
17	91010012	Lock washer (2 to 7.5 HP, not required for 10 to 15 HP)	4
18	93010143	Pipe plug 1/4" NPT	2

North America: 866 777 6060 Int'l: +1 267 404 2910 Springer Pumps Springer Parts

PROBLEM	PROBABLE CAUSE	CHECK
A) The pump does not prime,	1. Air leak in the suction system.	- Threaded joints in the suction tightness. - Gaskets for no wear. - The mechanical seal for leaks. - The drain plug has leaks. - The vacuum gauge may be leaking.
the vacuum gauge indicates a lower reading than normal.	2. Insufficient liquid in the pump casing.	- That the pump's body is filled with water.
lower reduing than normal.	3. Low operating speed.	- The motor speed (RPM).
	4. Bound pump.	- Impeller rotates freely. - Internal parts are clean.
	5. Mechanical defect.	- That the internal parts are not worn.
B) The pump does not prime, the vacuum gauge reading indicates higher than normal.	1. Pipe clogged suction.	- The suction line is clean.
C) The pump priming good vacuum gauge reading is normal, the manometer	1. The pump speed is very low.	- The voltage is correct.
indicates a lower pressure than normal.	2. Mechanical defects.	- The internal parts for wear.
D) The pump priming good vacuum gauge reading is	1. Discharge obstructed.	- The discharge is clear of obstructions.
almost normal, reading the manometer is greater.	n Discharge obstructed.	- That the discharge valves operate correctly.
E) The pump loses its priming	1. suction dynamic level too high.	- When the pump is operating, never lacks water in the suction.
E) The pump loses its priming during operation, vacuum gauge reading drops to zero.	2. The pump is sucking air.	 For leaks in suction piping, flanges and gaskets. That there is no vortex effect at the end of the suction this leaks fourtee.
	1. Pump base is loose.	the suction, this lack of water. - That screws are tight at the base. - There are no cracks in the base.
F) The pump priming pumps well and satisfactorily but noisy.	2. Cavitation.	 The dynamic level is not too high That the pumping capacity is not too much. The pump is operating in the range of NPSHR If reducing flow makes the noise gone, then the problem is in the point above; partially close the discharge valve.
SPRINGER	3. Bearings.	- The bearings for wear. - That there is oil in the deposit.
	4. Vibration.	- The impeller does not have any foreign material. - The pump is operating in the range. - That the alignment is correct.
	1. Low Voltage.	- The voltage is correct.
G) Motor overload.	2. Overload.	- The amperage of the plate is not exceeded. - There is no foreign material that may force

Risk of electric shock. Always disconnect the pump from the power source before handling inspections or repairs.

NOTE: Barmesa Pumps assumes no responsibility for damage or injury due to disassembly in the field. Disassembly of the pumps or supplied accessories other than at Barmesa Pumps or its authorized service centers, automatically voids warranty.

North America: 866 777 6060 Int'l: +1 267 404 2910

Springer Pumps Springer Parts

BARMESA PUMPS FACTORY WARRANTY

Barmesa Pumps warrants that products of our manufacture will be free of defects in material and workmanship under normal use and service for 18 months from date of manufacture or 12 months from installation date whichever occurs first. This warranty gives you specific legal rights, which vary from state to state.

This warranty is a limited warranty, and no warranty related claims of any nature whatsoever shall be made against Barmesa Pumps, until the ultimate consumer or his/her successor notifies us in writing of the defect and delivers the product and/or defective part(s) freight prepaid to our factory or nearest authorized service station as instructed by Barmesa Pumps. THERE SHALL BE NO FURTHER LIABILITY, WHETHER BASED ON WARRANTY, NEGLIGENCE OR OTHERWISE. PRODUCT SHALL BE EITHER REPLACED OR REPAIRED AT THE ELECTION OF BARMESA PUMPS. Guarantees relating to performance specifications provided in addition to the foregoing material and workmanship warranties on a product manufactured by Barmesa Pumps, if any, are subject to possible factory testing. Any additional guarantees, in the nature of certified performance specifications or time frame must be in writing and such writing must be signed by our authorized factory manager at time of order placement and/or at time of quotation. Due to inaccuracies in field testing and should a conflict arises between the results of field testing conducted by or for the user, Barmesa Pumps reserves the right to have the product returned to our factory for additional testing.

This warranty shall not apply when damage is caused by (1) improper installation, (2) improper voltage, (3) lightning, (4) excessive sand or other abrasive material, (5) corrosion build-up due to excessive chemical content or (6) uncontrollable acts of god. Any modification of the original equipment will also void the warranty. We will not be responsible for loss, damage or labor cost due to interruption of service caused by defective pumps, parts or systems. Barmesa Pumps will not accept charges incurred by others without our prior written approval.

This warranty is void if our inspection reveals the product was used in a manner inconsistent with normal industry practice and/or our specific recommendations. The purchaser is responsible for communication of all necessary information regarding the application and use of the product. UNDER NO CIRCUMSTANCES WILL WE BE RESPONSIBLE FOR ANY OTHER DIRECT OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO TRAVEL EXPENSES, CONTRACTOR FEES, UNAUTHORIZED REPAIR SHOP EXPENSES, LOST PROFITS, LOST INCOME, LABOR CHARGES, DELAYS IN PRODUCTION, IDLE PRODUCTION, WHICH DAMAGES ARE CAUSED BY ANY DEFECTS IN MATERIAL AND/OR WORKMANSHIP AND/OR DAMAGE OR DELAYS IN SHIPMENT. THIS WARRANTY IS EXPRESSLY IN LIEU OF ANY OTHER EXPRESS OR IMPLIED WARRANTY. No rights extended under this warranty shall be assigned to any other person, whether by operation of law or otherwise, without our prior written approval.

IMPORTANT! If you have a claim under the provision of the warranty, contact Barmesa Pumps or your authorized Barmesa Pumps Distributor: warranty@barmesapumps.com www.barmesapumps.com



Springer Pumps Springer Parts